

[Account](#)[Vehicle](#)[Help](#)[Search](#)[Contact](#)[AutoZone Community](#)[Exit](#)

Your Vehicle: 2010 Audi Q7 Quattro (4LB) V6-3.0L DSL Turbo (CATA)



**SAVE \$25**  
instantly on 4 tires!  
**SAVE \$25**  
instantly on 4 tires!

tirebuyer.com

[SAVE NOW >](#)

tirebuyer.com

[SAVE NOW >](#)

[Vehicle](#) » [Powertrain Management](#) » [Fuel Delivery and Air Induction](#) » [Turbocharger Control Module](#) » [Service and Repair](#)

## Service and Repair


### Turbocharger Control Module 1 (J724)

#### Special tools, testers and auxiliary items required

- ¤ Tool for Replacing E-Positioner on Turbo (VAS 6395A) or (VAS 6395)
- ¤ Wire Set (VAS 6395/2)
- ¤ Bracket (VAS 6395/5)

#### Removing


- Remove the engine cover - **arrows** -.



[Zoom](#)

[Sized for Print](#)

- Open the cover - **arrow** - over the positive terminal clamp.




[Zoom](#)

[Sized for Print](#)

- Connect the (VAS 6395) with the (VAS 6395/2) to the positive terminal and to the negative terminal.

Procedure for the E-box (VAS 6395/1A) :

- Select the software version using the [Up Arrow] - **5** - and [Down Arrow] - **6** - buttons.




Zoom

Sized for Print

- Press the v button - **4** - to confirm the software version.

¤ In this example, Hella software - **1** - is selected.

Procedure for the E-box (VAS 6395/1) :



[Zoom](#)

[Sized for Print](#)

Check the E-positioner tester (VAS 6395 /1) software version:

**Danger of damaging the turbocharger control module 1 (J724).**

- ☒ **Make sure the correct software is loaded in the (VAS 6395 /1) before performing the following procedure:**

If the correct software is loaded, the following will be displayed on the (VAS 6395/1) (2 seconds after the voltage supply is connected):

1. > 1. START

2. 2. NEXT [>]

- ☒ If the following appears in the display, then incorrect software has been loaded:


☒ 1. >TEST

☒ 2. LEARN

- ☒ If this is the case, then download the software from "Audi Service Net", "Workshop Equipment".

For both E-boxes:

- Disconnect the turbocharger control module 1 connector.




Zoom

Sized for Print

- Connect the (VAS 6395/2) to the turbocharger control module 1 and to the (VAS 6395 /1A).

The (VAS 6395 /1A) displays:



Zoom

Sized for Print


1. > 1. START

2. 2. NEXT [>]

- Press the v button - **4** - to continue.

¤ The (VAS 6395 /1A) checks the turbocharger control module 1 adjustment range in steps to determine if the end points are being reached. "CHECK" appears in the display.

(VAS 6395 /1A) display:




Zoom

Sized for Print

1.

2. [OK]

- ¤ If "[OK]" appears in the display, then the turbocharger control module 1 adjustment range is in order.
- ¤ If "FAULT [OK]" appears in the display, tap the side of the turbocharger control module 1 housing several times with a screwdriver handle and then touch the v button - **4** - to repeat the test.
- Tighten the countersunk bolts already installed in the (VAS 6395/5) to 8 Nm.




Zoom

Sized for Print

Incorrect measurement because the (VAS 6395/5) was secured incorrectly.

- ☒ Use only the countersunk bolts supplied with the bracket to secure it.
- ☒ Do not loosen the bracket until the procedure is completed.
  - Press the v button - 4 - to continue.




- ☒ To determine the voltage, the turbocharger control module 1 will check back and forth several times between the stops.
- ☒ Then the turbocharger control module 1 will go into the in installation position.
  - While determining the voltage, tap on the side of the turbocharger control module 1 housing with the handle of a screwdriver until the following appears in the display:

The r (VAS 6395 /1A) displays:


1. X,XXX V
  2. [[Up Arrow]][[Down Arrow]][OK]
    - Write down the voltage.
- ☒ Specified value: 3.3 to 3.7 V.
  - ☒ If "FAULT [OK]" appears or if the voltage is less than 3.3 V or greater than 3.7 V, disconnect the (VAS 6395 /1A) and repeat the entire procedure.

The (VAS 6395 /1A) displays:



## 2. [[Up Arrow]][[Down Arrow]][OK]


- Adjust the turbocharger control module 1 using the [Up Arrow] - **5** - or [Down Arrow] - **6** - buttons so that the coupling rod is accessible for removal.
- Remove the circlips - **arrows** - and disconnect the coupling rod.



Zoom

Sized for Print

The (VAS 6395 /1A) displays:




Zoom

Sized for Print

1. X,XXX V

2. [[Up Arrow]][[Down Arrow]][OK]

- Adjust turbocharger control module 1 using the [Up Arrow] - **5** - or [Down Arrow] - **6** - buttons so that the bolts for turbocharger control module 1 are accessible.
- Disconnect the (VAS 6395/2) from the turbocharger control module 1.




Zoom

Sized for Print

**The voltage supply for the (VAS 6395 /1A) must remain connected.**

- Remove the bolts - **1**, **2** and **3** - and dispose of them.



Zoom

Sized for Print

- Remove the old turbocharger control module 1 and dispose of it.

**Make sure there are 3 insulating washers between the turbocharger control module 1 and the bracket.**

- Install the new turbocharger control module 1 in reverse order.
- Install the new bolts as follows:

1. M6 x 15 with the narrow shaft


2. M6 x 15 with the narrow shaft

3. M6 x 15

- Only tighten the bolts by hand.

¤ The turbocharger control module 1 must contact the retaining plate without play, but it must be possible to move it by hand.


- Connect the (VAS 6395/2) to the new turbocharger control module 1.



Zoom

Sized for Print

- Press the v button - **4** - to continue.




[Zoom](#)

[Sized for Print](#)

The (VAS 6395 /1A) displays:

1. > 1. START
2. 2. NEXT [>]

- Select "NEXT" using the [Down Arrow] button - **6** -.
- Press the v button - **4** - to continue.



Zoom


Sized for Print

- ¤ The turbocharger control module 1 moves down the adjustment range.

The r (VAS 6395 /1A) displays:

1. X,XXX V
2. [OK]

- ¤ If "FAULT" appears in the display, then replace the new turbocharger control module 1 again.
  - Press the v button - **4** - to continue.




Zoom

Sized for Print

The (VAS 6395 /1A) displays:

- 1.
2. [OK]
  - Press the v button - **4** - to continue.




Zoom

Sized for Print

The (VAS 6395 /1A) displays:


1. X.XXX V (starting up voltage)
  2. [OK]
- ¤ The turbocharger control module 1 moves into the installation position.
- Install the coupling rod.



Zoom

Sized for Print


- ¤ Installation position: Attach the thicker eye to the turbocharger control module 1 shaft.
  - Install the circlips - **arrows** -.
- ¤ The circlips must engage audibly.
  - Gently push the turbocharger control module 1 to the rear - **arrow** -, just until the lever - **1** - touches the (VAS 6395/5).



Zoom

Sized for Print


- Hold the turbocharger 1 control module in this position.
- Tighten the bolts - **1, 2 and 3** - to 5 Nm.



[Zoom](#)

[Sized for Print](#)

- Press the v button - **4** - to continue.



[Zoom](#)


[Sized for Print](#)

- ☒ The turbocharger control module 1 will move back and forth several times between the stops and will be set to the start up voltage.

The (VAS 6395 /1A) displays:

1. X.XXX V (starting up voltage)
2. [OK]
  - ¤ If [OK] appears in the display, stop the adjustment.
  - ¤ If "CHECK" appears in the display, continue as follows.

Procedure, if "CHECK" Appears in the Display:



Zoom

Sized for Print


The (VAS 6395 /1A) displays:

1. [<<<]
2. CHECK

or

1. [>>>]
2. CHECK


- Loosen the bolts - **1, 2 and 3** - just enough so that is possible to move the turbocharger control module 1 with slight resistance in the direction specified.



Zoom

Sized for Print

- ¤ If [<<<] appears in the display, then slightly move the turbocharger control module 1 in direction of travel.
- ¤ If [>>>] appears in the display, slightly move the turbocharger control module 1 opposite the drive direction.
  - Tighten the bolts - **1, 2 and 3** - to 5 Nm.
  - Press the v button - **4** - to continue.




- ☒ The turbocharger control module 1 will move again back and forth several times between the stops and will be set to the start up voltage.


The (VAS 6395 /1A) displays:

1. X.XXX V (starting up voltage)
2. [OK]

Complete the Adjustment:



- Tighten the bolts - **1, 2 and 3** - to 10 Nm.
- Press the v button - **4** - to continue.




Zoom


Sized for Print

The (VAS 6395 /1A) displays:

1. X,XXX V
  2. [OK]
- Remove the (VAS 6395/5).



- Press the v button - **4** - to continue.



- ☒ The turbocharger control module 1 goes to the end points.
- ☒ If "FAULT" appears in the display, then replace the new turbocharger control module 1 again.

The (VAS 6395 /1A) displays:

- 1.
  2. [OK]
- ☒ The adjustment is complete.
    - Disconnect the (VAS 6395 /1A) connector.

Assembly is performed in reverse order.