

---

# Vehicle Relearn Instruction\*

Before beginning installation and vehicle relearn, verify application fitment with your parts provider or online at [www.vdo.com/usa](http://www.vdo.com/usa) or [www.redi-sensor.com](http://www.redi-sensor.com)

## SAP # V0511019876VW-B

1. Activate parking brake. Adjust tires to vehicle placard pressure.
2. Insert key, turn ignition ON (engine off).
3. Enter tire pressure mode through MEDIA CONTROL (located on center console).
4. Exit vehicle and allow to sit for 20 minutes.
5. Operate vehicle for a minimum of 10 minutes at a speed of 25 mph or more.

\* Procedure assumes OE (original equipment) wheels, OE tires, OE TPMS sensors (direct TPMS) or REDI-Sensor multi-application TPMS sensors (direct TPMS), and may vary if otherwise equipped.