


## Audi > B5 Platform > 1996 - 2002

### Heating & Air Conditioning

#### 87 - Air conditioning

### Control module for fresh air blower -J126- , removing and installing (1997 >)

- Remove fresh air blower -V2- and separate from base plate => page [87-117](#).



- Remove bolts -B-.
- Remove control module -A- from mounting plate.

#### **Note:**

*When installing control module, check foam seal -C-, must be used to seal mounting plate.*