



T3w Connector for RPM sensor –G28–

- at engine compartment bulkhead, left side, beneath coolant expansion tank; color–gray