


**Audi > C5 > 1998-2005
Communication
91 - Radio systems**

**Radio systems with Satellite Digital Audio Radio Service (SDARS) (Sedan),
component overview**



1 - Radio R

- In center console
- Removing and installing ⇒ ["Symphony" radio, removing and installing](#)

2 - Bass Speaker R100

- In right rear luggage compartment behind side trim
- Removing and installing [Bass Speaker R100 \(Sedan\), removing and installing](#)

3 - Amplifier R12 (only with "BOSE sound system")

- ✦ In right rear luggage compartment behind side trim
- ✦ Removing and installing ⇒ [BOSE Amplifier loudspeaker \(Sedan\), removing and installing](#)

4 - Antenna amplifier R82

- ✦ Behind right D-pillar trim (top)
- ✦ Removing and installing ⇒ [Antenna amplifiers - "Symphony" "Concert" radios \(Sedan\) from m.y. 2002, removing and installing](#)

5 - Auxiliary Heater Antenna R182

- ✦ On roof
- ✦ Also for Telematics and Navigation
- ✦ Removing and installing ⇒ [Satellite Tuner Antenna R172 \(Sedan\), removing and installing](#)

6 - Antenna amplifier R83

- ✦ Behind right D-pillar trim (bottom)
- ✦ Removing and installing ⇒ [Antenna amplifiers - "Symphony" "Concert" radios \(Sedan\) from m.y. 2002, removing and installing](#)

7 - Antenna amplifier R85

- ✦ Behind left D-pillar trim (top)
- ✦ Removing and installing ⇒ [Antenna amplifiers - "Symphony" "Concert" radios \(Sedan\) from m.y. 2002, removing and installing](#)

8 - Antenna amplifier R84

- ✦ Behind left D-pillar trim (bottom)
- ✦ Removing and installing ⇒ [Antenna amplifiers - "Symphony" "Concert" radios \(Sedan\) from m.y. 2002, removing and installing](#)

9 - CD Changer R41

- ✦ In left rear luggage compartment storage box
- ✦ Removing and installing ⇒ [CD Changer R41 , removing and installing](#)
- ✦ Check wiring

10 - Satellite Radio R146

- ✦ In left rear luggage compartment storage under CD changer
- ✦ Removing and installing ⇒ [Satellite Radio R146 \(Sedan\), removing and installing](#)

11 - Antenna Selection Control Module J515

- ✦ Below parcel shelf (left)
- ✦ Removing and installing ⇒ [Antenna Selection Control Module J515 \(Sedan\), removing and installing](#)

12 - Left Rear Bass Speaker R15 Right Rear Bass Speaker R17

- ✦ In lower rear door trim
- ✦ Removing and installing ⇒ [Loudspeakers in doors, removing and installing](#)

13 - Left Rear Midrange Speaker R34 Right Rear Midrange Speaker R35

- ✦ In upper rear door trim
- ✦ Removing and installing

14 - Left Front Bass Speaker R21 Right Front Bass Speaker R23

- ✦ In lower front door trim
- ✦ Removing and installing ⇒ [Loudspeakers in doors, removing and installing](#)

15 - Left Front Midrange Speaker R26 Right Front Midrange Speaker R27

- ✦ In upper front door trim
- ✦ Removing and installing