



- D - Ignition/Starter Switch
- J 59 - Load Reduction Relay
- J 217 - Transmission Control Module (TCM)
- J 234 - Airbag Control Module
- J 429 - Control module for central locking
- T 10 av - Connector 10 pin, yellow, connector station A pillar, right
- T 15 d - Connector 15 pin, black, connector station A pillar, right

- (A2) - Plus connection (15), in instrument panel wiring harness
- (A21) - Wire connection (86s), in instrument panel wiring harness
- (A52) - Plus connection (30), in instrument panel wiring harness