



85 86 87 88 89 90 91 92 93 94 95 96 97 98

97-19661

- G 70 - Mass Air Flow (MAF) Sensor
- G 130 - Oxygen Sensor (O2S) Behind Three Way Catalytic Converter (TWC)
- G 131 - Oxygen Sensor (O2S) 2 Behind Three Way Catalytic Converter (TWC)
- J 220 - Motronic Engine Control Module (ECM)
- N 112 - Secondary Air Injection (AIR) Solenoid Valve
- N 156 - Intake Manifold Change-Over Valve
- N 205 - Valve -1- for camshaft adjustment
- N 208 - Valve -2- for camshaft adjustment
- T 4 s - Connector 4 pin, green, near oxygen sensor, behind Three Way Catalytic Converter (TWC)
- T 4 t - Connector 4 pin, brown, near oxygen sensor 2, behind Three Way Catalytic Converter (TWC)
- T 10 o - Connector 10 pin, brown, connector station electronic box plenum chamber
- Z 29 - Heater for Lambda-probe 1
- Z 30 - Heater for Lambda-probe 2