



# Audi music interface

## Update for Audi music interface

This update is used to replace the driver for the Audi music interface. This may be necessary due to new generations of media players or due to new firmware versions.

To perform the update, you will need a standard USB stick with sufficient free memory space (at least 2 MB) and the USB adapter (available from your Audi dealer).

Please work through steps 1-7:

1. Load the driver update on your PC. Decompress the ZIP file and copy the decompressed BIN file onto the USB stick. Note:
  - The BIN file must be in the root directory (highest order directory) of the USB stick. A file stored in a subfolder will not be recognised by the Audi music interface.
  - The update file must be the only BIN file in the root directory.
2. Select the Audi music interface as active audio source.
3. Connect the USB adapter to the Audi music interface.
4. Plug the USB stick prepared as described in point 1 in the USB adapter. The following message appears: *"Initialising device. Please wait..."*
5. The update will take about 2 minutes. Please do not remove the USB stick during this time. The following message appears: *"Updating Audi music interface software. Please wait..."*
6. When the update has been successfully completed, the following message appears on the screen: *"Audi music interface software successfully updated."*
7. The update is complete.

Now remove the USB stick and the USB adapter. Your Audi music interface is ready for use again.