



LINE 30 IS POWERED WHEN BATTERY IS CONNECTED

IF YOU WANT TO CHECK THESE, THEY ARE IN ADAPTER C ON THE RELAY POWER.

- J191 - Power Window Opening Relay
- J192 - Power Window Closing Relay
- S24 - Fuse in auxiliary fuse holder (Convertible Top)
- S43 - Power Window Circuit Breaker, in Adapter C
- S64 - Power Window Circuit Breaker, in Adapter C

- (236) - Wire connection -2-, in central locking system/power window/power convertible top wiring harness
- (Q1) - Plus connection -1- (30), in central locking system/power window/power convertible top wiring harness
- (Q4) - Plus connection -2- (30), in central locking system/power window/power convertible top wiring harness
- (Q29) - Plus connection -3- (30), in central locking system/power window/power convertible top wiring harness

* - Fuses in Fuse Adapter C are installed in any free position and are not allocated any specific position