

- ▶ To remove, turn approximately 180 ° and pull off
- ▶ To install, push on and turn knob approximately 180 °
- ▶ Installed position

19 - Height adjustment clip

- ▶ Adjusting door trim panel height




Fig. 1 Number and location of tabs




Fig. 2 Disconnecting cable

1. Seal
2. Clip
3. Release cable

- ▶ When installing release cable - 3 - make sure that it is always hooked in from bottom to top
- ▶ When installing inside door release mechanism, lock all 4 tabs (- **arrows** - , 2 at top and 2 at bottom) in door trim panel