

Account

Vehicle

Help


Search

Contact

AutoZone Community

Exit

Your Vehicle: 2010 Audi Q7 Quattro (4LB) V6-3.0L DSL Turbo (CATA)



SAVE \$25
instantly on 4 tires!



SAVE NOW >

SAVE \$25
instantly on 4 tires!



SAVE NOW >

[Vehicle](#) » [Maintenance](#) » [Fuses and Circuit Breakers](#) » [Relay Box](#) » [Locations](#) » [Relay and Fuse Carrier](#)

Relay and Fuse Carrier


Relay

Relay and fuse carrier

Component Location:

Models with left-hand drive: In centre instrument panel





A97-10237

Zoom

Sized for Print

1 - Level Control System Compressor Relay -J403-

2.1 - Power Supply Relay (terminal 75x) -J694-

2.2 - Dual Horn Relay -J4-

3 - Headlamp Washer Relay -J39-

4 - Brake Light Disable Relay -J508-

5 - Not used

6 - Rear Window Defogger Relay -J9-

7.1 - Coolant Circulation Pump Relay -J151-

- ⌘ V6 TDI, V8 MPI/FSI, V12 TDI

- ⌘ V6 FSI from June 2009

7.1 - Engine Coolant Shut-Off Valve Relay -J541-

- ⌘ Only models with 6 cylinder diesel engine Generation II

7.2 - Automatic Day/Night Interior Mirror Relay -J910-

- ⌘ from June 2010

8 - Transmission Hydraulic Pump Relay -J510-

⌘ From June 2010, only models with 8-Speed Automatic Transmission

1a - Not used

2a - Not used

3a - Not used

[Account](#) | [Vehicle](#) | [Help](#) | [Contact](#) | [AutoZone Community](#) | [Exit](#)

© 2015 ALLDATA, LLC. All Rights Reserved. [Trademarks](#) | [Privacy Policy](#) | [Terms and Conditions](#)