

Account

Vehicle

Help

Search

Contact

AutoZone Community

Exit

Your Vehicle: 2010 Audi Q7 Quattro (4LB) V6-3.0L DSL Turbo (CATA)



SAVE \$25  
instantly on 4 tires!

tirebuyer.com

SAVE NOW >

SAVE \$25  
instantly on 4 tires!

tirebuyer.com

SAVE NOW >

[Vehicle](#) » [Accessories and Optional Equipment](#) » [Keyless Entry](#) » [Diagrams](#) » [Electrical Diagrams](#) » [Diagram 18/7 \(Tracks 71-84\)](#)



## Diagram 18/7 (Tracks 71-84)

### IMPORTANT NOTE:

This manufacturer uses "Track" style wiring diagrams.

For information on how to use these diagrams effectively, please refer to Diagram Information and Instructions. [See: Diagrams\Diagram Information and Instructions](#)

Keyless Access Authorization [Antenna](#) Reader, Access/Start Authorization Antenna



71 72 73 74 75 76 77 78 79 80 81 82 83 84  
 4L0-018070409

Zoom

Sized for Print

- ws = white
- sw = black
- ro = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- ge = yellow
- or = orange
- rs = pink

- G415** - Driver's Outside Door Handle Touch Sensor [See: Locations\Keyless Access Authorization System Exterior Door Handle Overview](#)
- G416** - Front Passenger's Outside Door Handle Touch Sensor [See: Locations\Keyless Access Authorization System Exterior Door Handle Overview](#)

- G417** - Left Rear Outside Door Handle Touch Sensor [See: Locations\Keyless Access Authorization System Exterior Door Handle Overview](#)
- G418** - Right Rear Outside Door Handle Touch Sensor [See: Locations\Keyless Access Authorization System Exterior Door Handle Overview](#)
- J723** - Keyless Access Authorization [Antenna](#) Reader [See: Locations\Overview Of Control Modules](#)
- R134** - Driver's Access/Start Authorization [Antenna](#) [See: Locations\Keyless Access Authorization System Overview](#)
- R135** - Front Passenger's Access/Start Authorization [Antenna](#) [See: Locations\Keyless Access Authorization System Overview](#)
- R137** - Luggage Compartment Access/Start Authorization [Antenna](#) [See: Locations\Keyless Access Authorization System Overview](#)
- R138** - Interior Access/Start Authorization [Antenna](#) 1 [See: Locations\Keyless Access Authorization System Overview](#)
- T20a** - 20-Pin Connector, black, front left door
- T20b** - 20-Pin Connector, black, front right door
- T20c** - 20-Pin Connector, black, rear left door
- T20d** - 20-Pin Connector, black, rear right door
- T20g** - 20-Pin Connector, red, on keyless access authorization [antenna](#) reader

Previous [See: Diagram 18/6 \(Tracks 57-70\)](#)

[Account](#) | [Vehicle](#) | [Help](#) | [Contact](#) | [AutoZone Community](#) | [Exit](#)

© 2015 ALLDATA, LLC. All Rights Reserved. [Trademarks](#) | [Privacy Policy](#) | [Terms and Conditions](#)