

## Door Lock Cover

### 1 - Securing Rod-Lock Cylinder

- Clip into socket at release lever.

### 2 - Door Handle

- Removing and installing, refer to → Chapter „Front Door Handle, from MY 1999 VIN 8D XA 200 001“

### 3 - Operating Rod-Door Lock

- Install as done for securing rod → Item.
- Clip length -a-:  $13 \pm 3$  mm.

### 4 - Cover For Door Lock

- To remove, unclip at top first then pull bottom toward rear of door lock and off.

### 5 - Installing Pin

- Only installed for new parts to help keep secure.
- Do not remove door lock until successfully installing operating rod.

### 6 - Operating Clip

- Engage in door lock, refer to → Anchor.

