

Capacities

Capacities

Planetary gearbox

Capacities	Planetary gearbox	Automatic transmission
Initial filling	9.0 liters (9.5 quarts)	01V
Changing	approx. 2.6 liters (2.75 quarts) ¹⁾	
Lubricant	VW ATF	
1) Life-time filling. Only replace after repair or removal of oil pan. Up to 3.5 L (3.7 qts)		

ATF is available as replacement (also referred to as VW ATF).

1.0 liter container: Part No. G 052 162 A2

ATF level, checking or changing => Page [37-113](#)

Front final drive

Capacities	Final drive	Automatic transmission
Initial filling	0.8 liters (0.85 quarts)	01V
Oil change	Filled for life No change	
Lubricant	Gear oil SAE75 W90 (synthetic oil)	

Note:

Gear oil SAE 75 W90 (synthetic oil) is available as a replacement part.

- ◆ 1.0 liter container: Part No. G 052 145 S2

Checking gear oil in front final drive and topping up => Page [39-1](#).

Transfer gearing

Capacities	Transfer gearing	Automatic transmission
Initial filling	0.8 liters (0.85 quarts)	01V
	Filled for life	

Oil change	No change	
Lubricant	Gear oil SAE75 W90 (synthetic oil)	

Note:

Gear oil SAE 75 W90 (synthetic oil) is available as a replacement part.

- ◆ 1.0 liter container: Part No. G 052 145 S2

Checking and topping up gear oil in differential => Page [39-40](#).

Rear final drive

Capacities	Final drive	Rear final drive
Initial filling	1.9 liters	01R
Oil change	Filled for life No change	
Lubricant	Hypoid gear oil SAE75 W90 (synthetic oil)	

Note:

Gear oil SAE 75 W90 (synthetic oil) is available as a replacement part.

- ◆ 1.0 liter container: Part No. G 052 145 S2

Checking and topping up gear oil in rear final drive => Page [39-92](#).